

SHORT FIELD TAKEOFF DISTANCE AT 2550 POUNDS

Conditions:

Flaps 10°
 Full Throttle Prior to Brake Release
 Paved level, dry runway
 Zero Wind
 Lift Off: 51 KIAS
 Speed at lift off: 56 KIAS

Press Alt In Feet	0°C		10°C		20°C		30°C		40°C	
	Grd Roll Ft	Total Ft to Clear 50 Ft Obst	Grd Roll Ft	Total Ft to Clear 50 Ft Obst	Grd Roll Ft	Total Ft to Clear 50 Ft Obst	Grd Roll Ft	Total Ft to Clear 50 Ft Obst	Grd Roll Ft	Total Ft to Clear 50 Ft Obst
S.L.	860	1465	925	1575	995	1690	1070	1810	1150	1945
1000	940	1600	1010	1720	1090	1850	1170	1990	1260	2135
2000	1025	1755	1110	1890	1195	2035	1285	2190	1380	2355
3000	1125	1925	1215	2080	1310	2240	1410	2420	1515	2605
4000	1235	2120	1335	2295	1440	2480	1550	2685	1660	2880
5000	1355	2345	1465	2545	1585	2755	1705	2975	1825	3205
6000	1495	2605	1615	2830	1745	3075	1875	3320	2010	3585
7000	1645	2910	1785	3170	1920	3440	2065	3730	2215	4045
8000	1820	3265	1970	3575	2120	3880	2280	4225	2450	4615

Notes:

1. Short field technique as specified in Section 4
2. Prior to takeoff from fields above 3000 ft. elevation, the mixture should be leaned to give maximum RPM in a full throttle, static runup.
3. Decrease distances 10% for each 9 knots headwind. For operation with tail winds up to 10 knots, increase distances by 10% for each 2 knots.
4. For operation on dry, grass runway, increase distances by 15% of the ground roll figure.